





## Typical Ditch Relief Culvert Installation



### Ditch relief culvert installation

- 1) The same basic steps followed for stream crossing installation shall be employed.
- 2) Culverts shall be installed at a 30 degree angle to the ditch to lessen the chance of inlet erosion and plugging.
- 3) Culverts shall be seated on the natural slope or at a minimum depth of 5 feet at the outside edge of the road, whichever is less.
- 4) At a minimum, culverts shall be installed at a slope of 2 to 4 percent steeper than the approaching ditch grade, or at least 5 inches every 10 feet.
- 5) Backfill shall be compacted from the bed to a depth of 1 foot or 1/3 of the culvert diameter, which ever is greater, over the top of the culvert.
- 6) Culvert outlets shall extend beyond the base of the road fill (or a flume downspout will be used). Culverts will be seated on the natural slope or at a depth of 5 feet at the outside edge of the road, whichever is less.

Pacific Watershed Associates Inc.

Geologic and Geomorphic Studies • Watershed Restoration • Wildland Hydrology • Erosion Control • Environmental Services  
PO Box 4433, Arcata, CA 95518 / Ph: 707-839-5130 / FAX: 707-839-8168 / [www.pacificwatershed.com](http://www.pacificwatershed.com)