



Typical Critical Dip Design for Stream Crossings with Diversion Potential




Critical Dip Construction:

1. Critical dip will be constructed on the lower side of crossing.
2. Critical dip will extend from the cutbank to the outside edge of the road surface. Be sure to fill inboard ditch, if present.
3. Critical dip will have a reverse grade (A) from cutbank to outside edge of road to ensure flow will not divert outside of crossing.
4. The rise in the reverse grade will be carried for about 10 to 20 feet and then return to original slope.
5. The transition from axis of bottom, through rising grade, to falling grade, will be in the road distance of at least 15 to 30 feet.
6. Critical dips are usually built perpendicular to the road surface to ensure that flow is directed back into the stream channel.

Typical Design of a Single-post Culvert Inlet Trash Rack


Cross section view



Plan view

Notes:


1. Many materials can be used for a single-post trash rack including old railroad track, galvanized pipe, and fence posts.
2. The diameter of single-post trash racks should be sized based on the size of expected woody debris. As a basic rule of thumb, the diameter of the trash rack should be equal to the diameter of the expected woody debris up to 4 inches.



Pacific Watershed Associates Inc.

Geologic and Geomorphic Studies • Watershed Restoration • Wildland Hydrology • Erosion Control • Environmental Services
 PO Box 4433, Arcata, CA 95518 / Ph: 707-839-5130 / FAX: 707-839-8168 / www.pacificwatershed.com

Rolling DIP (Typical)




ROAD GRADE (%)	TROUGH	A: REVERSE GRADE	B: UP ROAD APPROACH DOWN ROAD TAIL	
	Minimum depth below downslope crest	Minimum distance and grade from trough axis to downroad crest (ft)	Distance from up-road start of rolling dip to trough axis (ft)	Grade (%)
<5%	6 inches	15 feet at 5%	50	10%
10%			50	15%
15%			30	20%
>15%			7 feet at 10%	30

Rolling dip instructions:

- A rolling dip is a long, permanent dip constructed into native soils. The dip can be constructed to drain the inboard ditch or just the road surface.
- On existing roads the cut of the dip should start 30-50 feet upslope of the trough, with an outslope of 2-4%.
- Dip axis should be skewed down road at 30 degree off of centerline of road length – this will facilitate in efficiently draining the road without buildup of sediments in trough and makes the dip more drivable (i.e. the "roll" of the dip)
- The trough of the dip should be outsloped 3-5% with a flat reach of 2 feet.
- The reverse grade of the dip shall generally be sloped 5% for a minimum of 15 feet to form a minimum 6 inch deep dip. Road surface, where fill material will be placed, should be ripped first to ensure fill material interlocks with existing tread.
- The crest of the reverse grade should be a 2 foot long flat reach and the fill material should continue for a minimum of 30-50 feet before tapering to original grade.
- On roads steeper than 15% a steeper/shorter reverse-grade dip may be required.
- Dips shall be placed as specified in the plans. If not specified, then dips shall be placed at maximum 150-200 foot spacings.

Type 3 Rolling Dip Construction (steep slope outslope)




Notes

Rolling dip type 3 existing conditions: Type 3 rolling dips are utilized when roads grades are steeper than 12% grade with little opportunity to create reverse grade for the design vehicle, and there is proximal outfall adjacent to the outboard road to facilitate road drainage.

Design Notes:


- 1) The berm should be removed for the entire length of the outsloped section.
- 2) The dip should be outsloped at 2-4% across the road tread and 4-8% across the outboard fill. (The road log will specify the length of road to be type 3 outsloped).
- 3) The outsloping will rarely connect to and drain the ditch (see road log for specifications).
- 4) The road tread across the outsloped section or the outboard road will be rocked depending on site specific conditions (see road log).



Pacific Watershed Associates Inc.

Geologic and Geomorphic Studies • Watershed Restoration • Wildland Hydrology • Erosion Control • Environmental Services
PO Box 4433, Arcata, CA 95518 / Ph: 707-839-5130 / FAX: 707-839-8168 / www.pacificwatershed.com

Typical Road Surface Drainage by Waterbars



Waterbar installation:

1. Waterbar construction for seasonal use roads. Specifications are average and may be adjusted to conditions.
2. (A) tie-in cut and berm to cutbank.
3. (B) angle waterbar 30° - 40° downgrade with road centerline.
4. (C) berm height should be 4"-6" above the roadbed.
5. (D) cut depth should be 4"-6" into roadbed.
6. (E) approach should be 3'-4' length.

Waterbar spacing: 1,000/slope gradient

Example: @20% slope waterbar spacing = $1,000/20=50$ feet

Napa County Resource Conservation District

www.naparcd.org / 1303 Jefferson St, Suite 500B, Napa Ca, 94559 / (707)252-4188